VM3250 VM3250-2


Video Baby Monitor



Vtech Quick start guide

CCD





2.8" Colour LCD (QVGA 320x240 pixel) Channels 32 Parent unit: 2405 - 2475 MHz I ransmit frequency Saby unit: 2405 - 2475 MHz Crystal controlled PLL synthesizer Frequency control

TECHNICAL SPECIFICATIONS

IMPORTANT SAFETY INSTRUCTIONS

When using your equipment, basic safety precautions should always be followed to reduce the risk of fire,


- electric shock and injury, including the following: .. Follow all warnings and instructions marked on the
- Adult setup is required
- 3. CAUTION: Do not install the baby unit at a height
- 4. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be used as such.
- 5. This product is not intended for use as a medical
- 6. Do not use this product near water, for example, near to a bath, sink, swimming pool or showe
- 7. CAUTION: Use only the battery provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery in fire or a hot oven, mechanically crushing or cutting the battery can result in an explosion. Leaving the battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used batteries according to the instructions
- Use only the power adaptors included with this product. Incorrect power adaptor polarity or voltage can seriously damage the product.
- Parent unit output: 5V DC 1A Vtech Telecommunications Ltd Model:VT05EUK05100 (UK) / VT05EEU05100 (EU) Baby unit output: 6V DC 500mA n Pao Internatioal LTD. odel: S003ATB0600050 (UK) / S003ATV0600050 (EU)
- Rechargeable battery information: Zhuhai Great Power Energy Co., Ltd. Li-ion battery, 3.6V, 2600mAh, 9.36Wh; Model: ICR18650-2.6Ah-3.6V-1S1P
- 9. The power adaptors are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
- 10. For pluggable equipment, the socket-outlet should be installed near the equipment and should be easily 11. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a
- damp cloth for cleaning. Do not modify the power adaptors or replace with other adaptors, as this causes a hazardous situation.
- 13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked 14. This product should be operated only from the type of power source indicated on the marking label. If you
- are not sure of the type of power supply in your home 15. Do not overload wall outlets or use an extension cord. 16. Do not place this product on an unstable table, shelf,

stand or other unstable surfaces

- This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat
- 18. Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorised service facility. Disassembling or removing parts of the product other than via the battery door may expose you to dangerous voltages or other risks Incorrect reassembling can cause electric shock when the product is subsequently used.
- You should test the sound reception every time you turn on the units or move one of the components Periodically examine all components for damage.
- 2. There is a very low risk of privacy loss when using certain electronic devices, such as baby monitor cordless telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you are not intending to use it for some time.
- 23. The small parts of this monitor can be swallowed by babies or small children. Keep these parts out of reach
- 24. Children should be supervised to ensure that they do
- 25. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. SAVE THESE INSTRUCTIONS

- Use and store the product at a temperature between 0°C and 40°C .
- Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.
- Batteries should not be exposed to excessive heat such as bright sunshine or fire. Mishandling batteries can cause burn, fire or explosion
- Warning—Strangulation Hazard— Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 0.9m away). Do not remove warning label on the adaptor
- Never place the baby unit(s) inside the baby's cot or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket. Other electronic products may cause interference
- with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular relephones, intercoms, room monitors, televisions personal computers, kitchen appliances and

WHAT'S IN THE BOX




CONNECT THE BABY MONITOR

The parent unit turns on automatically after connecting the power adaptor to the power socket, and the battery LED light illuminates for a few seconds, then turns off. **■** NOTES

The rechargeable battery in the parent unit is built-in. Use only the power adaptors supplied with this product.

OVERVIEW - BABY UNIT

Make sure the baby monitor is not connected to an electronically-controlled electric outlet. Connect the power adaptors in a vertical or floor mount position only. The adaptor prongs are not designed to hold the weight of a baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adaptors may not properly connect to the outlets.



POWER LED light

CONNECT THE BABY MONITOR (CONT'D) Charge the parent unit battery When you have connected and turned on the parent unit, the battery will be charged automatically. ■ Notes Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon segments are solid \overline{full} . It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging. The standby time varies depending on the sensitivity level you set, your actual use and the age of

charge and may be used for 30 minutes).

The battery icon segments The battery is fully charged. To keep the battery charged, connect it to AC power when in use. are solid 📖 . POWER ON OR OFF THE BABY MONITOR


The battery has very little

The battery icon indicates the battery status (see the following table).

The screen displays 🔲.

Baby Unit turns on automatically

The **u** light flashes.





Press and hold POWER to power your parent

Charge without interruption (about

are more than 1 metre apart, **OR** Turn down the volume of your parent unit.

4 STATUS CHECK

(!) CAUTION

baby's cot or playpen.

your baby unit and parent unit, your parent unit displays images from the baby unit, and the **LINK** LED light turns on.

The baby unit **POWER** LED

noise from your baby monitor while



Basic Operation - Parent unit

Press MENU to enter the menu, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.


While in the menu:

Use the menu

- Press ◀ or ▶ to scroll among
- the menu options. Press **SELECT** or **▲** to enter the
- desired submenu. Press ▲ or ▼ to select an item.
- Press **SELECT** to confirm your selection.
- Press **5** or **▶** to exit the submenu.

Talk to your baby unit

Press and hold TALK and speak to your parent unit. Your voice is transmitted to the baby unit. When finished talking, release the **TALK** key to hear your baby




Turn off the screen

Press LCD ON/OFF (VM3250):

 Press and hold LCD ON/OFF (VM3250-2) to switch off the screen.

You can still hear sound from the selected baby unit.



渋 TIP

• Press any key on the parent unit to turn the screen on again.


Adjust parent unit speaker volume

 Pressing VOL+ / VOL- adjusts the parent unit speaker volume level received from




Zoom

Press \bigoplus to zoom in or out.



Overview - Parent unit



- LINK LED light
 - On when the parent unit is linked to the baby unit. Flashes when the link
- **Battery LED light Mute LED light**

🕀 Zoom / 🗢 Back

- to the baby unit is lost.
- TALK LED light
- CAM /LCD ON/OFF Arrow keys
- MENU/SELECT 10 **U** Power on/off

Press and hold to talk

to the baby unit.

- - Force reboot the
- 14 **VOL+ / VOL-**15 RESET
- 12 Power jack

Camera lens Speaker 4 Light sensor Slots for wall mounting

Microphon

■ PARENT UNIT ICONS

Status icons

Connection status

- Yill or Yil displays when strong signal strength is detected between the baby unit and the parent unit.
- Yii or Yi displays when moderate or low signal strength is detected between the baby unit and the parent unit.

21 or Current view status

Displays when the parent unit is in PATROL mode (For VM3250-2 only).

Displays the number of the baby unit that is being viewed.

Displays when the current image on the parent unit has zoomed in.

Displays when the baby unit being viewed has activated the night vision

Talkback Displays when talking back to the baby units from parent unit.

· Displays when a lullaby is playing.

• Displays when the parent unit speaker volume is set to zero.

- Displays when the parent unit is talking to the baby unit.

• Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. **57°F** or **14°C**). **Battery status**

- animates when the battery is charging.
- displays solid when the battery is fully charged.
- displays when the battery is low and needs charging.

Main menu icons

Brightness

Screen off timer

energy. You can still hear your baby while the screen is turned off.

VOX (Voice Activated Alert) Sensitivity When VOX is selected, the parent

- unit screen will automatically turn on when detected sounds exceed a set level. You can adjust the baby unit microphone
- sensitivity level so that the higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. For details, see the **Sound sensitivity and sound**

activation section.


- The parent unit will then turn off again after 50 seconds if the sound detected is lower than the set level. ■ Note
- · When the parent unit screen is off, if alerts are received, for example, no signal received between the parent unit and baby unit, or a low battery, the parent unit screen will turn on.

· Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the

The default volume of your parent unit The maximum volume is level 5. If you experience feedback

Positioning the baby monitor

To avoid interference from other electronic device place your baby monitor at least 1 metre away from devices such as wireless routers, microwaves, Make sure your baby unit and parent unit mobile phones and computers.





light turns on.




 Set the parent unit to beep whenever the room temperature







• Set temperature display in



PARENT UNIT ICONS (CONT'D)

Main menu icons Main Sub-menu

Lullaby

Lullaby volume




speaker volume when playing

· Select between two lullabies or

Adjust the selected baby unit

- stop 1 2 3 4
- two sounds to play or stop on the selected baby unit.

Monitoring Mode (For VM3250-2 only)



· Monitor your baby in PATROL mode, where the screen will cycle through the displays streamed from all the linked baby units (For VM3250-2 only).

Warning icons and messages



The battery is empty and needs to Battery low at be recharged.



The temperature detected by the baby unit is higher than the maximum temperature alert **Temperature**

Operation is in progress.



Temperature minimum temperature alert The parent unit is searching for baby units or the link between the

baby unit and the parent unit has

The temperature detected by

the baby unit is lower than the




The parent unit is connected to AC

Parent Unit Indication Lights

On when the parent unit is

linked to the baby unit. · Flashes when the link to the baby unit being viewed is



- Flashes when the parent unit battery is low and needs charging.
- Off when the parent unit is disconnected from AC

On when the parent unit


speaker volume level is set to zero. • On when the parent unit is

talking to the baby unit. On when the parent unit is talking to the baby unit.

Adjust the sound sensitivity of the baby unit

The parent unit screen will turn on only when the detected sounds exceed a set level.


Use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds that transmit to the parent unit. The VOX sensitivity level is preset to the highest level.




OX NSITIVITY VEL	Highest	High	Medium	Low	Lowest I
ESCRIPTION	The parent unit screen turns on for quiet sounds, (including background noises) from your baby's room.	The parent unit screen turns on for soft babbling and louder sounds from your baby. It remains off when your baby sleeps soundly.	The parent unit screen turns on for loud babbling and louder sounds from your baby. It remains off when your baby makes soft sounds.	The parent unit screen turns on for crying and louder sounds from your baby. It remains off when your baby makes soft sounds.	The parent unit screen turns on for loud crying or screeching sounds from your baby. It remains off when your baby makes soft sounds.

SOUND SENSITIVITY AND SOUND ACTIVATION

When **VOX** is selected, the parent unit screen stays off to save power when the baby unit detects sounds that are lower than the set sensitivity level. Once the baby unit detects sounds that are louder than the set sensitivity level, the parent unit screen turns on automatically. It will then turn off again after 50 seconds if the sounds detected are lower than the set sensitivity level.





DIM MODE

Dim mode helps you save parent unit power. Your parent unit display will automatically dim after 10 minutes of inactivity, when no keys are pressed or alerts are received from

(L)10 min inactivity





Press any buttons

Note

· While the screen is dimmed, any keypress or alert message will trigger the screen to return to the preset brightness level. After 10 minutes of inactivity, it will resume back to dim mode.

NIGHT VISION



The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and 2 ppears on the screen.

 It is normal to see a short white glare on your parent unit screen when the baby When the infrared LEDs are on, the mages are in black and white. This is

Depending on the surroundings and other interfering factors, for example, lighting, objects, colours and backgrounds, the image quality may vary. Adjust the baby unit angle or place the baby unit at a higher location to prevent glare and a blurred display.

FOR VM3250-2 ONLY

Status check - Two baby units

■Note

If you are viewing baby unit 21, the POWER LED light of baby unit 11 turns on. As baby unit **2** is not being viewed, its **POWER** LED light flashes.



· If you power on only one baby unit, your parent unit may display Ye and beep, and the LINK LED light will flash. Press 😝 to switch to the baby unit you have powered on.

Change different views - Patrol

- 1. Press **MENU** when the parent unit is idle.
- 2. Press ◀ or ▶ to choose ➡, then press **SELECT** or ▲.
- 3. Press ▼ or ▲ to choose on, then press **SELECT** to confirm your selection.







Change different views - Single-cam

Press CAM to switch to another camera in **SINGLE-CAM** mode.








MOUNT THE BABY UNIT ON DRY WALL (OPTIONAL)

Items to purchase

You will need to purchase the following items separately to mount your baby unit:

2 wall plugs 2 screws


 The types of screws and wall plugs you need depend on the composition of the



■ Note


angle before drilling the holes.

Make sure they are the same distance apart as the wall mount holes on the baby unit.




you drill the holes into a stud, go to step 3.

If you drill the holes into an object other than a stud, insert the wall plugs into the holes. Tap gently on the ends with a hammer until the wall plugs are flush with the wall.



tighten the screws until only 6.5 mm of the screws are exposed.



Align the wall mount holes on the baby unit with the screws on the wall. Slide the baby unit down until it locks



Q_{8∆} Frequently asked questions

Below are the questions most frequently asked about the baby monitor.

Why does the baby monitor not respond normally?

Try the following (in the order listed) for common cure: 1. Disconnect the power to the baby units and the parent unit. 2. Wait a few seconds before connecting power back to the baby units and the parent unit.

3. Turn on the baby units and the parent unit. 4. Wait for the parent unit to synchronise with the baby units. Allow up to one minute

Why doesn't the baby unit and parent

Perhaps the parent unit is not connected to the power. Insert the adaptor plug into the parent unit and insert the adaptor in a wall socket. Then, <u>press and hold</u> **POWER** to unit power-on light switch on the parent unit to establish connection with the baby unit. illuminate when the units Perhaps the baby unit is not connected to the power. Insert the adaptor plug into the are switched on?

Why doesn't my parent Make sure the power is not controlled by electronically controlled wall switch. unit charge while connected to AC power?

The battery may de degraded through extended use or defective. See Warranty for Why is my screen in The screen is in black and white during night-time or in a dark room when the night vision feature is activated. This is normal. black and white?

Why do I get glare or blurry display on my screen when viewing my parent unit screen. Adjust the baby unit angle or place the baby unit at a higher level to Why does the baby

Why does the parent

Why does the parent

connection lost every now

sound interruptions?

other sounds? Why don't I hear a

feedback noise?

unit beep?

prevent glare and a blurry display. The parent unit and baby units may be too close to each other.

Turn down the volume of your parent unit.

The baby units may be out of range. Move the parent unit closer to the baby units (but The parent unit may not have enough charge for the parent unit to perform normally.

baby unit and insert the adaptor in a wall socket. Then, establish a connection with the

During night-time or in a dark room, the surroundings and other interfering factors,

like lighting, objects, colours and backgrounds may affect the image guality on your

Charge the battery in the parent unit until the battery icon becomes solid **!!!** The temperature of your baby's room may be too high or too low.

The baby unit also picks up other sounds than those of your baby. Adjust the VOX unit react too quickly to sensitivity level to a lower level or lower the parent unit speaker volume. The parent unit speaker volume may be too low. See Adjust parent unit speaker

sound/Why can't I hear volume to increase the volume. Why can't I establish a The baby units may be out of range. Move the parent unit closer to the baby units (but connection? Why is the not less than 1 metre).

and then? Why are there baby monitor. Try installing your baby monitor as far away from these devices as possible. If you power on only one baby unit, your parent unit may display **%**, and the **LINK** LED light will flash.

Other electronic products and wireless products may cause interference with your

→ GENERAL PRODUCT CARE

To keep this product working well and looking good, follow these guidelines:

- · Avoid placing it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose it to direct sunlight or moisture.
- · Avoid dropping the product or treating it roughly.
- Clean with a damp cloth. DO NOT immerse the parent unit and the baby unit in water and do not clean under running water
- DO NOT use cleaning spray or liquid cleaners.
- Make sure the parent unit and the baby unit are dry before you connect them to the mains again.

When you are not going to use the video monitor for some time, store the parent unit, the baby unit and the adaptors in cool, dry location.

ADULT SUPERVISION

- This baby monitor should be for use by adults only.
- Do not place the baby unit inside the cot or playpen.
- To ensure your children's safety, do not allow them to touch or play with the baby monitor and its accessories. THIS IS NOT A TOY.

CUSTOMER SERVICE AND PRODUCT WARRANTY

PRODUCT WARRANTY ank you for choosing this quality product from VTech

- against any defects in materials or workmanship 2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe Plc (see address below), with proof of purchase
- 3. VTech Electronics Europe Plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorized repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable

without proof of purchase no replacement will be provided

- 6. Breakages to the LCD screen are not covered by the warranty 7. Products returned to VTech Electronics Europe Plc, should be sent to the address show
- below and packed carefully to avoid damage in transit. Please do not include batteries of adaptors. Please include details of the fault together with your name and address, contact phone number and/or email addres
- To keep an online record of your warranty, please register your product online at www.vtech.co.uk/clubvtech

VTech Electronics Europe Plc, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

nty is valid for the UK and Ireland only. For products pu the UK and Ireland, please contact your local distributor or place of purchase.

IMPORTAN1

Please retain this booklet with your sales receipt as proof of the date of purchase.

Please visit www.vtechphones.eu to contact our Customer Service Department.

DISPOSAL OF BATTERIES AND PRODUCT

The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



www.vtechphones.eu.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in Battery Directive (2006/66/EC).


The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.


DECLARATION OF CONFORMITY

This product is intended for use within Europe and UK. This equipment complies with the essential requirements to EU's Radio Equipment Directive


(2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication VTech Telecommunications Ltd. hereby declares that this Video Monitor VM3250/VM3250-2 is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EU) and UK's Radio Equipment Regulations 2017.



Manufacturer: VTech Telecommunications Ltd. 23/F., Tai Ping Industrial Centre, Block 1, 57 Ting kok Road, Tai Po, Hong Kong. Importer: VTech Electronics Europe Plc Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT, U.K.



· Check for reception strength and camera Use a pencil to mark two holes in parallel



Adjust the baby unit angle.